

CRAWFORD F4

Bulletin F4.07.09.19

Maintenance Advisory

1 ACCUMULATOR MAINTAINANCE

Parts

CCF4-07-013 ACCUMULATOR ASSEMBLY

To ensure optimum functioning of the gear change system, we advise regular maintenance of the air lines from the pump to the valve block. The main issue that need to be checked on a regular basis, is fluid collecting in the accumulator.

We would advise checking for fluid as part of a routine maintenance schedule, especially in wet, or conditions of high humidity, when the pump will draw in water vapor. Failure to follow this can lead to corrosion occuring in the system which can lead to poor shifting, or system failure

