

NHT Processor remote controller

- All values in decimal form
- All codes RC5 toggle type
- Carrier frequency 36kHz

Specification v 2.0

Button	Man #	ID #
Power toggle	16	12
Power ON	16	35
Power OFF	16	34
SRC1	16	1
SRC2	16	2
SRC3	16	3
SRC4	16	4
SRC5	16	5
SRC6	16	6
SRC7	16	7
SRC8	16	8
SRC9	16	9
SRC10	16	10
Direct	16	67
Movie	16	68
Music	16	69
Games	16	70
UP	16	80
DOWN	16	81
LEFT	16	85
RIGHT	16	86
OK	16	87
Menu	16	82
Esc	16	83
Status	16	84
Mute toggle	16	13
Mute ON	16	107
Mute OFF	16	108
Dyn	16	62
Tune +	16	43
Tune -	16	44
Band	16	45
Trim +	16	102
Trim -	16	103
Trim select	16	104
Mode +	16	32
Mode -	16	33
Zone control	16	59
Volume +	16	16
Volume -	16	17

Button	Man #	ID #
Tuner preset 1	16	91
Tuner preset 2	16	92
Tuner preset 3	16	93
Tuner preset 4	16	94
Tuner preset 5	16	95
Tuner preset 6	16	96
Tuner preset 7	16	97
Tuner preset 8	16	98
Tuner preset 9	16	99
Tuner preset 10	16	100
Bass +	16	22
Bass -	16	23
Treble +	16	24
Treble -	16	25
Center +	16	26
Center -	16	27
Surround +	16	18
Surround -	16	19
Sub +	16	20
Sub -	16	21
Zone SRC1	19	1
Zone SRC2	19	2
Zone SRC3	19	3
Zone SRC4	19	4
Zone SRC5	19	5
Zone SRC6	19	6
Zone Pwr toggle	19	12
Zone Mute	19	13
Zone Power OFF	19	34
Zone Power ON	19	35
Zone Source +	19	80
Zone Source -	19	81
Zone Volume +	19	16
Zone Volume -	19	17
Zone Mute ON	19	107
Zone Mute OFF	19	108

