



## TECHNICAL REGULATION BULLETIN

**No:** TRBF4-2018-001  
**Date:** April 4, 2018  
**To:** All  
**Subject:** Holes for Belts in Extraction Seat

The F4 extraction seat is delivered with clearance holes sized to allow attaching the lap belts to the rearward anchor points in the tub. For the shoulder belts, the seat is delivered with slots at the top, sized to attach the shoulder belts to the upper anchor points in the tub.

To allow attachment of the lap belts to the forward anchor points in the tub, it is permitted to enlarge the clearance hole in the extraction seat.

To allow attachment of the shoulder belts to the lower anchor points in the tub, it is permitted to create a new clearance hole in the extraction seat, located directly adjacent to the anchor points, and sized no larger than necessary to permit free passage of the shoulder belt.

Note that the extraction seat clearance holes should insure both that the belts are not damaged by rubbing the extraction seat as well as allowing removal of the extraction seat without the use of tools. If a seat insert is used, it should have adequate belt clearance to allow free removal of the extraction seat.